




BELVEDERE FIRE PIT KIT

Matches Belvedere Texture




Belvedere Fire Pit Kit Pallet: 1,275 lbs


TOP VIEW




CROSS-SECTION



BLOCK LAYOUT PATTERN FOR BELVEDERE FIRE PIT



BLOCK KEY
(Nominal Dimensions)



INSTALLATION INSTRUCTIONS:

1. Familiarize yourself with the construction details shown on this sheet.
2. Mark out the location for your fire pit. Note dimensions shown are nominal so mark an area slightly larger than shown.
3. Excavate for drain stone base (approx. 6")
4. Fill excavated area with drain stone. Level, and compact the stone.
5. Place and center steel ring on prepared base.
6. Place blocks per the pattern. (For Round Kit, keep Blocks 1 1/2" off steel ring)
7. **WARNING:** Do not place Rosetta Fire Pits directly on Rosetta Flagstone products or any comparable concrete product as high heat can adversely affect the integrity of the product.
8. After placing blocks around the ring, adjust the blocks in or out to make the circle close and fit tight. If the blocks do not close the circle, move all blocks slightly in. If the blocks seem too long, move the blocks slightly out.
9. Place caps in circle around fire pit. Adjust the caps in or out to make them fit tightly together.
10. Note: Not suitable for large fires. Fire size should not allow flame to contact Caps on Round Fire Pit.

*Gas Conversion Kits Available

IMPORTANT NOTE: Burning large items or trash in fire pits may cause damage to block units. Our fire features are designed strictly for small campfires. We recommend using a steel insert to protect block and coping units. Failure to use an insert could cause damage to the block or coping.