

Thank you for choosing Rosetta hardscape products. The following are some helpful tips to make your first installation go smoothly. For more in-depth technical information, see our Belvedere Technical Guide (available at discoverrosetta.com) or contact Bob Conklin with Rosetta Technical Support at (877) 777-6558 ext 3081.

Your safety is important to us. Please follow OSHA guidelines, and utilize safety-toe boots, hardhats, gloves and eye, ear & respiratory protection whenever appropriate.

PATTERNS

- Wall patterns are available in our Belvedere Technical Guide, but are not necessary or recommended for most applications

BLEND MULTIPLE PALLETS

- In order to achieve the best possible color blend, utilize material from multiple pallets simultaneously (when applicable).

GLUING

- For additional strength, adhere rows of block together with landscape adhesive.

MINIMUM CONVEX RADIUS

- Convex curved walls can be made with a minimum radius of 4½ ft.

HEIGHT VARIATION

- Due to the manufacturing process, some minor variation in product height is possible. Shimming or grinding blocks may be necessary in some applications.

REQUIRED TOOLS

- PLATE COMPACTOR
- SHOVEL
- RAKE
- LEVEL
- DEAD BLOW HAMMER
- LANDSCAPE ADHESIVE

OPTIONAL TOOLS:

- CUT OFF SAW
- ANGLE GRINDER
- SHIMS

OTHER:


- NON-WOVEN GEOTEXTILE FABRIC
- 4" PERFORATED DRAIN PIPE
- GEOGRID

BELVEDERE COLLECTION


QUICK INSTALL TIPS

TYPICAL RETAINING WALL SECTIONS


GRAVITY, NON-REINFORCED (0-2 FT TALL WITH NO SURCHARGE)



REINFORCED (GREATER THAN 2 FT TALL OR AS REQUIRED IN BELVEDERE TECHNICAL GUIDE)



TYPICAL FREESTANDING WALL SECTION



COLUMN INSTALLATION

*Requires Corner Blocks

